

SPRUCE COFFEE TABLE

Predrill screw holes through the middle of the grooves in the top side pieces, then join all the slats to one top side edge using #10 x 3" wood screws without glue. Repeat to attach the other opposite top side. This dry-fit is meant to see how everything comes together.

Apply the post and foot assemblies onto the stretcher ends. Tap in the wedges to secure the base assembly.

Choose Spruce

